



National Aeronautics and
Space Administration



EcAMSat and BioSentinel: Autonomous Bio Nanosatellites Addressing Strategic Knowledge Gaps for Manned Spaceflight Beyond LEO

Mike Padgen, Ph.D.

Millennium Engineering and Integration Co.

NASA Ames Research Center

SUNY CNSE Colloquium

March 24, 2017



National Aeronautics and
Space Administration



Ames Research Center

- 1 of 9 NASA Field Centers
- Located in Silicon Valley
- Second oldest NASA facility
 - Est. 1939 as part of National Advisory Committee for Aeronautics (NACA)
 - Absorbed into NASA in 1958
- ~2300 employees





Image taken aboard ISS






National Aeronautics and
Space Administration



What We Do at Ames

- National Full-Scale Aerodynamics Complex
 - 80x120' wind tunnel is largest in the world
- Unitary Plan Wind Tunnel
 - 3 test sections, most commercial & military aircraft tested here
 - Mercury, Gemini, Apollo capsules
- NextGen Air Transportation






National Aeronautics and
Space Administration



What We Do at Ames

- ARC Jet
 - Creates super hot plasmas to help simulate re-entry
 - Only facility capable of modeling re-entry from interplanetary space
- Pleiades supercomputer
 - 13th fastest in world
 - Appeared in The Martian!



Space shuttle wing tests




National Aeronautics and
Space Administration



What We Do at Ames: Flight Missions

- Pioneer missions (1970s)
- LADEE and LCROSS
 - Measured structure and composition of the thin lunar atmosphere
- Kepler and K2 Missions
 - ~2500 confirmed exoplanets
- ISS Life Sciences
 - Wet-Lab 2, molecular biology in space!
 - Rodent research
 - Fruit fly lab



Inscription on Pioneer 9 and 10



Kepler




National Aeronautics and
Space Administration



Ames Has a History of Successful Bio Nanosats


- Nanosats are small, autonomous, free-flying satellites
 - Less reliance on human-tended experiments
 - Access to space: Low-cost launches as secondary payloads
 - Multiple flights possible - test, learn, iterate
 - Excellent education vehicle: Significant academic participation worldwide
 - Peer-reviewed science experiments

GeneSat-1




4.4 kg, 3U (2006)

PharmaSat



5.1 kg, 3U
(2009)

O/OREOS





5.5 kg, 3U (2010)

1U = 10x10x10 cm



A Quick Intro to AlamarBlue

- Metabolic indicator dye
 - Reduced by FAD, NADPH, cytochromes
 - Color change from blue to pink
 - Increase in fluorescence
 - Shift in absorbance
- Used by PharmaSat, O/Oreos, EcAMSat and BioSentinel





National Aeronautics and
Space Administration








GeneSat-1: 1st biological nanosatellite in Earth orbit, 1st real-time, *in-situ* gene expression measurement in space

- Launch: December 2006
- Nutrient deprivation in dormant state
- Nutrient delivered upon orbit stabilization
- GFP to measure gene expression
- OD to measure cell population



E. coli






National Aeronautics and
Space Administration





PharmaSat: Effect of Microgravity on Yeast Susceptibility to Antifungal Drugs

- Grow yeast in multiwell fluidics card in μ -gravity
 - Measure inhibition of growth by antifungal
 - Optical absorbance (turbidity: cell density)
 - Metabolism indicator dye: Alamar Blue
 - Control + 3 concentrations of antifungal



S. cerevisiae








National Aeronautics and
Space Administration



O/OREOS: Effects of Space exposure on biological organisms (6 mo) and organic molecules (18 mo)

- 2 x 1U payloads
 - SESLO: Monitor survival, growth, metabolism of *Bacillus subtilis*: *in-situ* OD / colorimetry
 - SEVO Track changes in organic molecules and biomarkers: UV / visible / NIR spectroscopy



O/OREOS: Organism/Organic Response to Orbital Stress

SESLO: Space Environment Survival of Living Organisms

SEVO: Space Environment Viability of Organics

Wayne L. Nicholson, *et al.* Astrobiology, Vol. 11, Issue 10, Dec. 2011, pp. 951-958

Andrew Mattioda, *et al.* Astrobiology, Vol. 12, No 9, 2012

Nathan E. Bramall, *et al.* Planetary and Space Science, Vol. 60, 2012, pp: 121-130

Amanda M. Cook, *et al.* Astrobiology, February 2014, Vol. 14, Issue 2, pp: 87-101



National Aeronautics and
Space Administration




Addressing Strategic Knowledge Gaps

- If humans are to go further into space for longer:
 - Model organisms can help us understand and mitigate key biological risks
 - Direct impact on human health or performance
 - Impact on the biota that accompany humans
 - Impact on organisms used to process waste or produce food
- Deep space radiation
- Long-term exposure to microgravity



National Aeronautics and
Space Administration



EcAMSat

E. coli Anti-Microbial Satellite



National Aeronautics and
Space Administration



EcAMSat Team

- PI: AC Matin, Stanford University
- Stevan Spremo, PM
- Current Team: Matt Chin, Tori Chinn, Aaron Cohen, Charlie Friedericks, Mike Henschke, Chris Kitts, Mike Miller, Mike Padgen, Macarena Parra, Mario Perez, Mike Rasay, Tony Ricco, Tim Snyder
- Support from NASA's Human Exploration and Operations Mission Directorate (HEOMD) as a Small Complete Mission of Opportunity in Fundamental Space Biology.



National Aeronautics and
Space Administration




For Astronaut Health During Long Term Spaceflight, Many Questions Remain

- Immediate need to understand antibiotic resistance in microgravity
 - Evidence that bacteria become more virulent and resistant than in normal gravity
 - Astronaut's immune system is compromised in microgravity
- Model Organism: uropathogenic *Escherichia coli* (UPEC)
 - Urinary tract infections have been reported in astronauts
 - Gentamicin has been used to treat UTI
 - WT and Δ rpoS mutant strains
 - rpoS responsible for activating general stress response (GSR)
 - GSR increases antibiotic resistance


Gentamicin Resistance Increases in Low-Shear Cellular Suspensions

High-aspect-ratio vessels
(HARVs)



- **Control**: rotation about a vertical axis
- **Low-shear suspension**: rotation about a horizontal axis

- HARVs used to simulate microgravity, although experimental results in actual microgravity can vary





National Aeronautics and
Space Administration



EcAMSat is a Re-flight of PharmaSat Hardware

- EcAMSat will measure growth and metabolic activity of *E. coli* treated with antibiotic in microgravity compared to the ground control
- PharmaSat measured growth and metabolic activity of yeast treated with antifungal in microgravity compared to ground control
- Yeast → *E. coli*
 - Filter pore size: 1.2 μm → 0.2 μm
 - Higher pressure in fluidic system
 - Experiment temperature: 27°C → 37°C
 - More power required
 - Storage: dry → wet




National Aeronautics and
Space Administration



EcAMSat is the First* NASA 6U Mission

- Overall size: 10 x 22 x 34 cm
- Passive magnetic orientation
- UHF Beacon and S-band radio
- Extensive thermal power management testing and modeling
- Mission Ops run by Santa Clara University




* See slide 24



National Aeronautics and
Space Administration



Experiment Design






National Aeronautics and
Space Administration



EcAMSat Fluidic Card




- WT and mutant strains loaded into alternating wells prior to sealing
- Each bank is independent and will receive a different dose of antibiotic during the experiment



National Aeronautics and
Space Administration



Fluidic System Schematic



SV: Solenoid valve




National Aeronautics and
Space Administration




Assembled Payload

Fluidic Payload



Hermetic Payload Can





Can is 2U or roughly 10x10x20 cm



Experiment Verification on Ground

- Payload can rotated on rotisserie to prevent settling of cells
- Experiment run through “flight like” commanding
- Optics data calibrated and normalized
- Growth of wild type and mutant are similar






National Aeronautics and
Space Administration



Evaluating the Effect of Gentamicin on *E. coli*

- Clear differences between wild type and mutant in control
- At each dose there was a significant difference in the ability of the cells to reduce alamarBlue relative to the control case





National Aeronautics and
Space Administration



EcAMSat Summary

- EcAMSat leverages hardware from successful PharmaSat mission
 - Fluidic system provides accurate dilution of antibiotic and consistent delivery to the fluidics card housing the biology
- Uropathogenic *E. coli* model organism for studying changes in antibiotic resistance in microgravity
 - Extensive ground control tests already performed in addition to a 24 hr delayed synchronous ground control
 - Differences between WT and mutant strain missing key stress response gene, *rpoS*, can yield insight into mechanisms responsible for these changes
 - Help determine if therapies developed on ground will be successful in flight



National Aeronautics and
Space Administration



Where are we now?


- Original scheduled launch: July 2015
 - Falcon 9 (SpaceX) FormoSat 5 + SHERPA
 - 6 launch delays
 - SHERPA de-manifested Jan 2017
- Current launch: Falcon 9 date TBD



National Aeronautics and
Space Administration



BIOSENTINEL



MSFC

JPL

JSC

AES



National Aeronautics and
Space Administration



BioSentinel Team

- Bob Hanel, PM; Dawn McIntosh, Deputy PM
- Sharmila Bhattacharya, PI
- BioSensor Payload Team: Chetan Angadi, Josh Benton, Rich Bielawski, Justin Blaich, Travis Boone, James Chartres, Michael Dougherty, Lance Ellingson, Charlie Friedericks, Diana Gentry, Sarah Hayes, Mike Henschke, Liz Hyde, Ben Klamm, Diana Marina, Eddy Mazmanian, Griffin McCutcheon, Mike Padgen, Macarena Parra, Mario Perez, Abe Rademacher, Tony Ricco, Sergio Santa Maria, Aaron Schooley, Ann-Sofie Schreurs, Ming Tan, Eric Tapio, Huyen Tran
- NASA/Ames, NASA/JSC-Radworks, Loma Linda U. Med. Ctr., U. Saskatchewan
- Support from NASA's Advanced Exploration Systems and Human Exploration and Operations Mission Directorate



National Aeronautics and
Space Administration




***BioSentinel* Space Radiation BioSensor Experiment & Mission**

- BioSentinel is a 6U free-flying satellite to be delivered by NASA's Exploration Mission 1 (EM-1) to a heliocentric interplanetary orbit
 - First biology experiment beyond LEO since Apollo!
- Model organism, *S. cerevisiae* (brewer's yeast) will be used to measure effects of deep space radiation on DNA damage
 - Help to understand, quantify, and potentially mitigate key biological risk




National Aeronautics and
Space Administration

Ames



BioSentinel Science Mission: “Canary in a Coal Mine”


- Quantify DNA damage from space radiation environment
 - Space environment cannot be reproduced on Earth: *omnidirectional, continuous, low flux, variety of particle types*
 - Health risk for humans spending long durations beyond LEO
 - Radiation flux can spike 1000x during a solar particle event (SPE)
- Correlate biological response with physical radiation measurements
 - Linear Energy Transfer (LET) spectrometer bins and counts particle events by LET
 - Total Ionizing Dose (TID) sensor measures integrated deposited energy





BioSentinel Science Mission: “Canary in a Coal Mine”


- Yeast assay: microfluidic arrays monitor DSB/repair
 - Three strains of *S. cerevisiae*: 1 wild type, 1 radiation sensitive mutant, and 1 engineered strain
 - *engineered strain quantifies double strand breaks (DSBs)*
 - Wet and activate multiple banks of microwells over mission lifetime
 - Double strand break & associated repair enable cell growth & division
 - Reserve wells activated autonomously in case of SPE





BioSentinel: a Biosensor in Space


- What: BioSentinel is a yeast radiation biosensor that will measure the DNA damage caused by space radiation, specifically double strand breaks (DSBs).



In yeast diploid cells, NHEJ is inhibited. Thus, HR is the main repair pathway for DSBs

One of our yeast strains is engineered in such a way that only the repaired cells will grow actively in the media provided and will be detected by optical density (OD) & colorimetric measurements

S. cerevisiae
(budding yeast)





National Aeronautics and
Space Administration



Spacecraft Configuration

Low-Gain
Antenna

Command & Data
Handling/Power/Transponder
Stack

Propulsion
System
 $(\text{CF}_3)_2\text{CH}_2$

Batteries

Integrated
Guidance
Navigation
& Control
Unit

Star Tracker
Cutout


Medium-
Gain
Antenna

Radiation Sensors:
TID + LET spectrometer

Solar Arrays

Solar Array Gimbal

Bio Payload Container (4U, 4.5 kg)






National Aeronautics and
Space Administration



Experiment Design



Note: A delayed synchronous ground control will be run






National Aeronautics and
Space Administration




Bio-fluidic-opto-thermal Configuration

16-well card
= 1 “set”
(18 sets total)






Bio-Fluidic-Opto-Thermal Cross Section




- Yeast dried onto μ well walls
- 3 LEDs + detector, per well, track growth *via* optical density and cell metabolic activity *via* dye color changes.
- LEDs: 570, 630, 850 nm

*Yeast growth with flight-like
prototype fluidic card + optics*




BioSentinel Payload: *Design/Function Highlights*

Card Box



- Two card manifolds and two bag manifolds
- Each card controlled independently and has its own desiccant

Bag Box



KEY



Fluidic
card



3-way
valve



FEP tubing



Internal channels



Check valve



Desiccant
trap



Polishing
bubble trap



Calibration
cell



Hermetic
feed-thru



Desiccant



carbon cloth





National Aeronautics and
Space Administration



SPE Autonomous Trigger for BioSensor



- Onboard TID monitor
- Ionizing EM radiation (gamma) precedes particles by \sim hours
 - SPE differentiable from smaller coronal mass ejections
- Activate “designated SPE set” of fluidic wells
 - measure radiation biological damage under wet conditions
 - *expected to generate more damage wet than in dry state (OH•)*





Radiation Sensitivity of Yeast Cells in Fluidics Cards

- Gamma, protons, iron, oxygen, silicon radiation sources have been used to quantify effects
- 2-year old air-dried cells are responsive to high-energy particle irradiation at 250 cGy (expected dose in a 12-month mission).





National Aeronautics and
Space Administration



Summary of BioSentinel

- BioSentinel will be the first biology experiment outside of LEO since Apollo
- Heliocentric orbit will provide a deep space radiation environment for a 12 month mission
- *S. cerevisiae* as a model organism will measure the effect of deep space radiation on DNA damage
 - Help to understand, quantify, and potentially mitigate key biological risk
- Demonstration of a deep space biosensor
 - Potential follow-on missions: Mars Sentinel, radiation shielding



National Aeronautics and
Space Administration



Where are We Now?

- Building engineering development units for qualification and testing
- Long-term biocompatibility tests in progress
- Radiation testing, including SPE simulation
- Launch for SLS EM-1: Sept 30, 2018

